




Installation and Maintenance Manual

ACO Access Covers - SERVOKAT GD



ENG **Installation Manual**

GER **Installationsanleitung**

FRA **Instructions d'installation**

ESP **Manual De Instalación**

POR **Manual de Instalação**

ITA **Manuale d'installazione**

NLD **Installatiehandleiding**

CZE **Instalační manuál**

RUS **Инструкция По Установке**

SWE **Installationsanvisning**

NOR **Installasjons Manual**

FIN **Asennusohje**

DAN **Installationsvejledning**

EST **Paigaldusjuhend**

LAV **Uzstādīšanas instrukcija**

LIT **Montavimo instrukcija**

POL **Instrukcja montażu**

BUL **Инструкции за инсталация**

HUN **Beépítési útmutató**


RUM **Instructiuni de instalare**







HRV **Upute za ugradnju**






SLV **Navodila za vgradnjo**






SRP **Preporuka za ugradnju**


TUR **ACO Mühahale Kapakları**














5

 $F \leq 25 \text{ kg}$ ✓ $F > 25 \text{ kg}$ ✗

**ACO. creating
the future of drainage**

www.aco-accesscovers.com



Article Number: **NM11560** ACO Access Covers - SERVOKAT GD/EN/06/19